

# QUICK START GUIDE

## SUPERSLOT WIRELESS SLEEVES

### 1. Screw on bezel (if needed)

Align the bezel and tighten screws.



### 2. Slide in slot receiver

Making sure the DB-25 connector is in the correct orientation, slide the receiver into the sleeve.



### 3. Tighten receiver screws

Attach the screws through the receiver holes to the bezel and sleeve.

